## **XYZ Company**

### Service Checklist

#### **Client Information**

Name: 12sadfs

Contact: Jon Stewart Doe | Phone: 89232322332.

Address: Rua Inexistente, 2000 Authorized Signature: Engineer 9



### **Screw Compressor Checklist**

Task	Done	Remark
Make safe as instructed in the service manual	Yes	Works: B-2 Sara Industrial Estate, Shankarpur, Hukumatpur, Dehradun-248197 Office: C-111/112 New Multan Nagar, New Delhi-110056 GST NO: 05AAACA1814D1ZI
Carry out repair (after obtaining authorization, if needed)	No	
Check abnormality in Ambient air like Bad odor / Heavy dust	No	
Check control cabinet / cooler filter mats, clean / replace if necessary	No	
Check / clean cooler, check fan blades and guarding	No	
Check coupling / belt tension, tight if necessary	No	
Check / change oil separator cartridge	No	
Check oil separator cartridge, diff. pressure	No	
Check / change the Air filter	No	
Check Air filter cap, Suction hose for any leak or crack / damage	No	
Check / change the Oil filter	No	
Check / change the Oil	No	
Check / change the Valve kits	No	
Check motor bearing lubrication, regrease if necessary	No	
Check electrical connection and tight	No	

Task	Done	Remark
if necessary		
Check motor overcurrent relays and protection switches	No	
Check door and guard interlocks and emergency stop function	No	
Check all sensor connections and tight if necessary	No	
Check and register if any safety device bypassed	No	
Check Control voltage; L1 12V, 18V V, Logo Power Output 12V, 18V V DC.	Yes	Works: B-2 Sara Industrial Estate, Shankarpur, Hukumatpur, Dehradun-248197 Office: C-111/112 New Multan Nagar, New Delhi-110056 GST NO: 05AAACA1814D1ZI
Check line voltage: L1 6, 16, 32, 45 V, L2 6, 16, 32, 45 V, L3 6, 16, 32, 45 V 6, 16, 32, 45	Yes	Works: B-2 Sara Industrial Estate, Shankarpur, Hukumatpur, Dehradun-248197 Office: C-111/112 New Multan Nagar, New Delhi-110056 GST NO: 05AAACA1814D1ZI
Check current consumption: Line U1 A, V1 A, W1 A	No	
Check Fan motor current Fan 1 U1 A, V1 A, W1 A	No	
Check Fan motor current Fan 2 U1 A, V1 A, W1 A	No	
Room temp: C, Airend discharge temp.: C	No	
Pressure Setting: SP bar, SD bar	No	
Check for any Air / Oil leakages in the compressor	No	
Check and maintain ZK filter Eco drain Valve	No	
Test run, check conditions: start, idle, load and shut-down	No	

# Refrigerator Checklist

Task	Done	Remark
Check refrigerant levels	No	Works: B-2 Sara Industrial Estate, Shankarpur, Hukumatpur, Dehradun-248197 Office: C-111/112 New Multan Nagar, New Delhi-110056 GST NO: 05AAACA1814D1ZI
Inspect evaporator and condenser coils	No	Works: B-2 Sara Industrial Estate, Shankarpur, Hukumatpur, Dehradun-248197 Office: C-111/112 New Multan Nagar, New Delhi-110056 GST NO: 05AAACA1814D1ZI

Task	Done	Remark
Check door seals for damage	No	
Clean drain pan and ensure proper drainage	No	
Verify thermostat operation	No	
Check / clean Air dryer condenser	No	
Check condenser fan motor direction	No	
Check condensate drain function	No	
Check refrigerant circuit and Air circuit for leaks	No	
Check compressed air temperature: Inlet °C   Outlet °C	No	
Check current consumption: Line U1 A, V1 A, W1 A	No	
Check Auto On/Off operation; Switching On C, Switching Off C	Yes	Works: B-2 Sara Industrial Estate, Shankarpur, Hukumatpur, Dehradun-248197 Office: C-111/112 New Multan Nagar, New Delhi-110056 GST NO: 05AAACA1814D1ZI
Pressure dew point [] blue [] green [] red °F/C	Yes	Works: B-2 Sara Industrial Estate, Shankarpur, Hukumatpur, Dehradun-248197 Office: C-111/112 New Multan Nagar, New Delhi-110056 GST NO: 05AAACA1814D1ZI
Check / Replace Air treatment filter cartridge	Yes	Works: B-2 Sara Industrial Estate, Shankarpur, Hukumatpur, Dehradun-248197 Office: C-111/112 New Multan Nagar, New Delhi-110056 GST NO: 05AAACA1814D1ZI

Generated on: 9/25/2024, 1:40:50 PM © XYZ Company